ASSEMBLY INSTRUCTIONS

ITEM CODE : IN 1803

ITEM DESCRIPTION: 4 DRAWER MEDIA UNIT




1

Reverse the media unit & place the leg as shown & align the leg to match the apron.



Insert the Bolt to fix the leg with the media unit top and tighten the nut with the washer as shown in fig1

2



3

Fix the other leg in the similar way



Reverse the media unit straight. Now your media unit is ready for use

4



Fig. 1

