
ASSEMBLY INSTRUCTIONS


ITEM CODE : **IN662**

ITEM DESCRIPTION : **SQUARE CHIP DRAWER FRONT MEDIA UNIT**




1

Reverse the Media unit & place the leg as shown & align the leg to match the apron.



Insert the Bolt to fix the leg with the Media unit top and tighten the nut with the washer as shown in fig1

2



3

Fix the other pair of legs in the similar way





Fig. 1



Reverse the unit straight. Now your Media unit is ready for use

4

